



Panasonic KX-TGE233 Battery Replacement

This guide will give you instructions on how to remove and replace the batteries in the Panasonic KX-TGE233 handsets. The batteries are located on the back of the handset behind a removable panel.

Written By: Nico Cruz



INTRODUCTION

This is a quick guide on where to locate the batteries in any of the handsets and how to access/replace them. Before any of the other repair guides can be started, the user must remove the batteries as described in this guide.

Step 1 — Battery



- Flip the handset over to expose the back panel, and slide the panel out to remove.

Step 2



- Carefully remove the two batteries by lifting up from one end.

To reassemble your device, follow these instructions in reverse order.

